

Email: info@aquilogic.com
Telephone: +1.714.770.8040

The Contamination Experts

Responsible Party Identification

GIS and Geomatics

Contaminant Hydrogeology

Fate and Transport Modeling

Risk Assessment

Remediation Feasibility Studies

Soil and Groundwater Remediation

Natural Resource Damage Assessment

Water Resources Assessment

Source Water Assessment and Protection

Drinking Water Treatment

Environmental Risk Management

Litigation Support/Expert Witness

Forensic Engineering

Stakeholder/Public Participation

Regulatory Strategy



To contact us, or sign up for our newsletter, please scan here.

www.aquilogic.com



















Oil Field Contamination

Contamination at oil fields can result from the production, transmission and storage of crude oil, and releases of other oil field chemicals (e.g. produced water/brines, diluent, barium drilling fluids, arsenic biocide). The figure at right highlights some, but not all, possible contaminant release mechanisms at oil fields. However, it is important to note that many of these activities are no longer permitted at active oil fields, and contamination is often the result of past practices.

If any processing of the crude oil takes place at the oil field, increased volumes of lighter-fraction hydrocarbons (e.g. gasoline, diesel) and aromatics (e.g. benzene) may be present, as well as additional contaminants used in oil processing, such as sulfolane. In some cases, refined product additives may also be present, such as methyl tertiary butyl ether (MTBE), ethanol and other fuel oxygenates.


Crude oil is a mixture of hundreds of individual chemicals, notably paraffins (straight chained hydrocarbons), iso-paraffins (branched hydrocarbons), cyclo-hexanes (single-bond, ring hydrocarbons), aromatic hydrocarbons (with a single benzene-ring), and poly-aromatics hydrocarbons (PAHs). The lighter (lower carbon content) chemicals are usually present as a gas (e.g. methane). Crude oil also contains trace heavy metals, notably nickel, vanadium, copper, cadmium and lead, and naturally occurring radioactive materials (NORMs), notably radium 226 and 228. Sour-oil/gas also contains high concentrations of sulfur.

Most paraffins, iso-paraffins and cyclo-hexanes have very low solubility in water, are relatively immobile in the environment, and have limited toxicological effects. However, aromatics and PAHs have higher solubility in water, are somewhat mobile in the environment, and have known toxicological impacts at relatively low concentrations. The aromatics of primary concern are the volatile organic compounds (VOCs) benzene, toluene, ethylbenzene and xylenes (BTEX). The PAHs of primary concern are napthalene, benzo(a)pyrene, benz(a)anthracene, benzo(b) fluoranthene, benzo(k)fluoranthene and chrysene.

In addition to crude oil constituents, other chemicals are often present at an oil field, including produced water/brines, barium sulfate in drilling fluids, diluent used to thin the crude (usually diesel-range hydrocarbons), biocides containing arsenic, pump corrosion inhibitors (usually containing hexavalent chromium), and smaller quantities of industrial solvents.

Aside from pure petroleum product found as a light non-aqueous phase liquid (LNAPL), BTEX and PAHs are the most common chemicals found in soil and groundwater contaminated by oil field activities.

Contaminant Release Mechanisms




Properties of Common Petroleum Contaminants


		Molecular weight	Boiling Point	Density	Vapor Pressure	Sorption (Log K _{oc})	Log K _{ow}	Solubility	Henry's Constant	Regulatory Levels		
Chemical Type	Compound	(g/mol)	(∘C)	(g/cm ³)	(mmHg)	(unitless)	(unitless)	(mg/L)	(unitless)	CA PHG (μg/L)	CA MCL (µg/L)	US MCL (μg/L)
Aromatic VOCs	Benzene	78.11	80.1	0.88	76	1.82	1.99	1,770	0.227	0.15	1/NS	5
	Toluene	92.14	111	0.87	28.2	2.15	2.54	530	0.276	150	150	1000
	Ethylbenzene	106.17	136	0.87	9.6	2.31	3.03	169	0.327	300	300	700
	O-Xylene	106.17	144	0.88	6.75	2.11	3.13	178	0.0007	1800	1750	10,000
PAHs	Napthalene	128.17	218	1.14	0.09	3.19	3.17	31.4	0.02	-	170 (AL)	-
	Benzo(a)pyrene	252.31	495	1.24	4.89x10 ⁻⁹	5.98	6.11	0.0016	0.000047	0.004	0.2	0.2
	Benz(a)anthracene	228.29	438	1.19	1.5x10 ⁻⁷	5.55	5.52	0.01	0.00014	0.04	-	-
	Chrysene	228.29	448	1.27	7.8x10 ⁻⁹	5.49	5.52	0.002	0.00005	0.4	-	-
Oxygenates	МТВЕ	88.15	55.2	0.74	249	1.15	1.43	48,000	0.024	13	13	20-40
	ТВА	74.12	82.4	0.79	31.4	0.62	0.69	Miscible	0.0003	-	12 (AL)	NS
	Ethanol	46.07	78.4	0.79	32.6	0.08	0.002	Miscible	0.002	-	NS	NS
Process	Sulfolane	120.17	285	1.26	0.0006	-0.79	-0.80	8370	0.000009	-	87.5 (AK)	-

PHG = public health goal

MCL = maximum contaminant level

AL = action level





strategy ● environment ● water ● strategy ● environment ● water ● strategy ● environment ● water ● strategy §